



# product release notes

D86ASM51NLR2.4

These release notes are divided into the following sections:

**MANUAL UPDATE**

**TOOL-SPECIFIC NOTES**

**DOS OPERATION-SPECIFIC NOTES**

**MANUAL UPDATE**

The following information should be added to the *MCS<sup>R</sup>-51 Utilities User's Guide for DOS Systems* manual:

## **OH FOR MICROCONTROLLERS**

The OH is a tool included with the RL-51 for 8051 products. OH is an object file converter that converts an absolute 8051 object file to a hex file. These hex files can be used with tools that do not accept Intel standard object file formats.

### **Invocation Syntax**

The invocation syntax for OH is:

```
OH objfilename [TO hexfilename]
```

Where:

*objfilename* is an absolute 8051 object file

*hexfilename* is the file containing the hexadecimal output

Copyright 1988, Intel Corporation, All Rights Reserved

If a *hexfilename* is not specified, the output file name defaults to the root of the object file name with a .hex extension.

## Examples:

The following example converts the absolute 8051 object file and placed the output into a hexadecimal format file.

```
OH save1.obj TO save.h51
```

The next example does not specify a hexadecimal output filename.

```
OH tot2.obj
```

The hexadecimal file is now called tot2.hex

## Output File

The following is a sample hex output:

```
:10000300850A83850B827401F02275080275090045
:0800130085080A85090B1103A1
:0300000002001BE0
:09001B0075810C75D00002000D86
:00000001FF
```

In the output file, the record format is:

:	length	offset	type	content	checksum
---	--------	--------	------	---------	----------

Where:

: is the record header

*length* are the next two hex digits representing the record length. OH outputs records of 16 bytes or less, causing most records to start with :10

*offset* are the next four hex digits representing the offset from the record's beginning

*type* are the next two hex digits 00 representing the record type

*content* are the next two hex digits representing each content byte

*checksum* are the remaining two hex digits

Each record in the file contains 16 bytes. If the information available for a record is greater than 16 bytes, OH divides it into 16 byte sections. If there are remaining bytes after this operation, they are combined with bytes left over from adjacent records in memory. These adjacent bytes in the OH buffer, may be from previous, or following records. If there are no adjacent bytes available for combination, OH puts the extra bytes on a new line.

The hexadecimal file ends with the following module end record:

:00000001FF

## Error Messages

OH error messages are fatal errors. Processing of the object file is stopped and one of the following error messages is issued:

\*\*\* ERROR - invocation should be: OH <infile> [TO outfile>]

The invocation syntax is incorrect. OH expected the TO keyword but found something else. Re-invoke OH using the correct syntax

\*\*\* ERROR - input is not an absolute object file

The object file is not absolutely located.

\*\*\* ERROR - input has a record longer than 32K, sorry

Make sure the records in the file are less than 32K bytes

\*\*\* ERROR - on reading OBJECT: I/O error in invalid object file

OH has detected an invalid format. Be sure the object file is available, and that it is an absolutely located file.

## Errors

In appendix B of the *MCS<sup>R</sup>-51 Utilities User's Guide for DOS Systems*, order number 122747 several error messages are missing. Error messages 114-120, 122-127 and fatal errors 201-207 are not listed. Following are the missing error messages:

ERROR 114: SEGMENT DOES NOT FIT  
SEGMENT:                *segment-name, base, length*

The specified segment cannot be located at the base specified by the locating control. Starting at that base address there is insufficient memory for a segment of its length. The specified segment is ignored.

ERROR 115: INPAGE SEGMENT IS GREATER THAN 256 BYTES  
SEGMENT:                *segment-name*

The specified INPAGE segment is greater than one page. The specified segment is ignored.

ERROR 116: INBLOCK SEGMENT IS GREATER THAN 2047 BYTES  
SEGMENT:                *segment-name*

The specified INBLOCK segment is greater than one block. The specified segment is ignored.

ERROR 117: BIT ADDRESSABLE SEGMENT IS GREATER THAN 16 BYTES  
SEGMENT:                *segment-name*

The specified BIT-ADDRESSABLE segment is greater than the bit space. The specified segment is ignored.

ERROR 118: REFERENCE MADE TO ERRONEOUS EXTERNAL  
SYMBOL:                *external-name*  
MODULE:                *file-name (module-name)*  
REFERENCE:              *code-address*

The specified, ignored external symbol is referenced in the specified module at the specified code address.

**ERROR 119: REFERENCE MADE TO ERRONEOUS SEGMENT**

SYMBOL:                *segment-name*  
MODULE:                *file-name (module-name)*  
REFERENCE:             *code-address*

A symbol, which is defined using the specified, but ignored, segment, is referenced in the specified module at the specified code address.

**ERROR 120: CONTENT BELONGS TO ERRONEOUS SEGMENT**

SYMBOL:                *segment-name*  
MODULE:                *file-name (module-name)*

A content record, which belong to the specified, but ignored, segment, has been encountered. The content record is not relocated.

**ERROR 122: CANNOT FIND MODULE**

MODULE:                *file-name (module-name)*

The specified module name, which was explicitly requested from the specified file (in the command tail), was not found in that file.

**ERROR 123: ABSOLUTE IDATA SEGMENT DOES NOT FIT**

MODULE:                *file-name (module-name)*  
FROM:                   *data-address*  
TO:                      *data-address*

The specified module contains an absolute IDATA segment that occupies non-existent internal RAM space in the target machine. The segment is ignored. Notice, however, that the module may contain erroneous references to this segment, which are not reported.

**ERROR 124: RESERVED**

**ERROR 125: MORE ERRORS ENCOUNTERED NOT REPORTED**

Non-fatal errors encountered henceforth will not be reported.

**ERROR 126: OVERLAY MODULE NOT FOUND**

MODULE:                *file-name (module-name)*

The specified module name explicitly mentioned in the overlay control was not found.

ERROR 126: OVERLAY DATA ADDRESS SPACE OVERFLOW  
SPACE: *on-chipRAM space*

RL-51 was unable to allocate an overlaid segment of the specified address space. Try to link with the NOOVERLAY control.

### **Fatal Errors**

FATAL ERROR 201: INVALID COMMAND LINE SYNTAX  
*partial command*

A syntax error was detected in the command. The command is repeated up to and including the point of error.

FATAL ERROR 202: INVALID COMMAND LINE; TOKEN TOO LONG  
*partial command*

A command line contains a token that is too long. The command is repeated up to and including the point of error.

FATAL ERROR 203: EXPECTED ITEM MISSING  
*partial command*

An expected item in the command line, such as an input file name or a file name following the TO is missing. The command is repeated up to and including the point of error.

FATAL ERROR 204: INVALID KEY WORD  
*partial command*

An invalid key word was found in the command. The command is repeated up to and including the point of error.

FATAL ERROR 205: NUMERIC CONSTANT TOO LARGE  
*partial command*

A numeric constant greater than 0FFFFH was found in the command. The command is repeated up to and including the point of error.

FATAL ERROR 206: INVALID CONSTANT  
*partial command*

An illegally constructed context was found. A common example of this error is entering a hexadecimal number with a letter first. The command is repeated up to and including the point of error.

FATAL ERROR 207: INVALID NAME  
*partial command*

An illegally constructed name was found. Names can be from 1 through 40 characters long and must be composed of the letters A-Z, the digits 0-9, or special characters (?,@, ). The first character must be a letter or a special character. The command is repeated up to and including the point of error.

There are some errors in the *MCS<sup>R</sup>-51 Macro Assembler User's Guide for DOS Systems*, order number 122752. These errors are:

Disregard any reference to a manual called the *MCS-51 Family Of Single-Chip Microcomputer User's Guide*, order number 121517. This manual is no longer available.

Disregard any reference to a manual called the *Universal PROM Programmer Reference Manual*, order number 9800133. This manual is no longer available.

In Chapter 7, "Assembler Output: Error Messages and Listing File Format", the message for ERROR 34 is incorrect. It should read, "The maximum number of external symbols referred to by a single module (255) has been exceeded."

In Appendix J a cross-reference to Chapter 6 is made regarding a complete description of all the error messages. The cross-reference should be to Chapter 7.

## TOOL-SPECIFIC NOTES

### CROSS REFERENCE HEADING

The cross reference heading in the list file does not conform to the PAGEWIDTH control.

### CROSS REFERENCE LISTING

Single character symbols have an additional character appended in the cross reference listing. The problem occurs only when the NAME is greater than 30 characters.

Example:

```
NAME The_appended_character_name_program
EXTERN DATA (A,B,C,ASKIT)
CSEG AT 0
END
```

To correct the cross reference listing, remove characters from the NAME directive.

### PDF FILE CHANGES

The assembler is distributed with Processor Definition Files (PDF) for members of the MCS-51 family. Each of the PDF files contains definitions of the special function registers of one MCS-51 member. These files are:

```
REG44.PDF
REG51.PDF
REG52.PDF
REG152.PDF
RG51FA.PDF
RG51FB.PDF
REG451.PDF
REG452.PDF
```

For more information about PDF files see Appendix L of the *MCS<sup>R</sup>-51 Macro Assembler User's Guide for DOS Systems*.



## **SYMBOL TABLE LIMITATIONS**

<b>ASM51</b>	1314 six character symbols or with the NOMACRO control 2400 six character symbols.
<b>RL51</b>	2600 ten character symbols.

## **DOS OPERATION-SPECIFIC NOTES**

### **DIRECTING OUTPUT TO A FULL DISK**

When directing output to a full disk, an Intel translator or Relocation and Linkage (R & L) tool may terminate prematurely without giving any error message. Make sure your disk has sufficient space to contain any output these tools may generate before invoking them.

### **FILE SHARING CONFLICTS**

File sharing conflicts may occur when using an Intel translator or R & L tool in a network environment. Before invoking an Intel translator or R & L tool (with network support), invoke the DOS V3.0 or later SHARE command. It is recommended that you invoke the SHARE command in your AUTOEXEC.BAT file.

### **USER-DEFINED LOGICAL NAMES**

Confusion may occur on user-defined logical names. The default assignments for :F0: through :F9: and :WORK: are not in the user documentation. If these logical devices are not defined with the SET command, the default assignments for :F0: through :F9: are to devices A through J. The default assignment for :WORK: is the current default disk. Use the SET command to assign the desired logical devices.

### **USING CTRL-BREAK VERSUS CTRL-C**

CTRL-C does not work as the interrupt character like CTRL-BREAK. Use CTRL-BREAK instead of CTRL-C.

## **FILES CONSISTING OF AN 8-DIGIT HEX NUMBER**

Files consisting of an 8-digit hex number with no extension may be left in the current :WORK: directory after typing CTRL-BREAK to abort an Intel translator or R & L tool or a user program converted to DOS with UDI2DOS.EXE. These are temporary files created by these programs to store intermediate data. They are normally deleted at the end of a program's normal execution. Delete or ignore the files. No important information is contained in them.

## **FATAL ERROR SPECIFYING LONG PATHNAMES**

A fatal error is flagged when specifying long pathnames for output files, and the translator or R & L tool aborts. While the DOS manual indicates that the maximum number of characters in a pathname is 63, in practice various products seem to restrict pathnames to less than 63 characters. To ensure compatibility with all products, make sure that all output pathnames do not exceed 43 characters.

## **ERROR #21 --- FILE DOES NOT EXIST**

This message is issued by the Operating System even though the file does exist. The PC/DOS Operating System is installed incorrectly. Re-install the Operating System and make sure that it is DOS V3.0 or later. DOS V3.0 or greater has a different COMMAND.COM file.

## **SHARING VIOLATION ERROR READING DRIVE**

This message is returned when a program, which has been invoked by a command file, is interrupted in the middle of that process by a system reset and you later attempt to access that file. If you have directed output from that command file, the same error also appears for that output file. This does not occur on Intel NRM file servers but may occur on other types of networks. A system reset may leave these files open, thus they cannot be reopened. Avoid resetting the system while a command file is executing on the network. You can type CTRL-BREAK's until the command file has exited.

## **INPUT/OUTPUT FILE CONTENTS MAY BE LOST**

The contents of a file may be lost when the same file is specified for input and output to a translator or R & L tool. Depending on the order in which a translator or R & L tool opens the input and output files, the file may be overwritten if it is used for both input and output. When a file is opened for output on DOS, any previous contents are lost unless the file is already opened for input and the SHARE command is in effect. When invoking a translator or R & L tool under DOS, ensure that the output filename differs from the input filename.

## **DOS ERRORLEVEL**

The MCS-51 assembler sets the DOS ERRORLEVEL variable as follows:

- 0 No warnings or errors
- 1 Warnings occurred
- 2 Errors occurred
- 3 Fatal Errors occurred

## TABLE OF CONTENTS

	PAGE
Program Status Word .....	1
Operand Definitions .....	1
Arithmetic Instructions .....	2
Logical Instructions .....	3
Data Move Instructions .....	4
Bit Manipulation Instructions .....	5
Non-Operation .....	5
Program and Machine Control Instructions .....	6
Codes for Instructions Using Registers .....	7
Predefined Byte Addresses .....	8
Predefined Code Addresses .....	8
Predefined Bit Addresses .....	9
Macro Processor Language (MPL) Functions .....	10
Assembly Time Expression Operators .....	11
Assembler Directives .....	11
Table of Instruction Opcodes in Hexadecimal Order .....	12
Hex-ASCII Table .....	18

## PROGRAM STATUS WORD (PSW—0D0H)

C	AC	F0	RS1	RS0	OV		P
7	6	5	4	3	2	1	0

C	Carry Flag
AC	Auxiliary Carry Flag
F0	Flag 0
RS1	Register Bank Select
RS0	Register Bank Select
OV	Overflow Flag
PSW 1	Not Used
P	Parity

## OPERAND DEFINITIONS

Operand	Meaning
<i>#data</i>	data coded in instruction
<i>data addr</i>	on-chip memory address
<i>Rr</i>	0 ≤ <i>r</i> ≤ 7 General-Purpose register
<i>a:Rr</i>	0 ≤ <i>r</i> ≤ 1 Indirect address register
<i>code addr</i>	16-bit address encoded as: full 16-bit 11-bit page address 6-bit relative offset
A	Accumulator
C	Carry flag
<i>bit addr</i>	bit address (on-chip)
<i>/bit addr</i>	complemented contents of bit address
DPTR	Data Pointer
PC	Program Counter
AB	Register Pair

## ARITHMETIC INSTRUCTIONS

Hex Code	Mnemonic	Operands
24	ADD	A, #data
26	ADD	A, @R0
27		R1
2*	ADD	A, Rr
25	ADD	A, data addr
34	ADDC	A, #data
36	ADDC	A, @R0
37		R1
3*	ADDC	A, Rr
35	ADDC	A, data addr
94	SUBB	A, #data
96	SUBB	A, @R0
97		R1
9*	SUBB	A, Rr
95	SUBB	A, data addr
04	INC	A
06	INC	@R0
07		R1
0*	INC	Rr
05	INC	data addr
A3	INC	DPTR
14	DEC	A
16	DEC	@R0
17		R1
1*	DEC	Rr
15	DEC	data addr
A4	MUL	AB
84	DIV	AB
D4	DA	A

\* See page 7 for instruction's hex code.

## LOGICAL INSTRUCTIONS

Hex Code	Mnemonic	Operands
54	ANL	A, #data
56	ANL	A, @R0
57		R1
5*	ANL	A, Rr
55	ANL	A, data addr
53	ANL	data addr, #data
52	ANL	data addr, A
44	ORL	A, #data
46	ORL	A, @R0
47		R1
4*	ORL	A, Rr
45	ORL	A, data addr
43	ORL	data addr, #data
42	ORL	data addr, A
64	XRL	A, #data
66	XRL	A, @R0
67		R1
6*	XRL	A, Rr
65	XRL	A, data addr
63	XRL	data addr, #data
62	XRL	data addr, A
E4	CLR	A
F4	CPL	A
23	RL	A
33	RLC	A
03	RR	A
13	RRC	A
C4	SWAP	A

\* See page 7 for instruction's hex code.

## DATA MOVE INSTRUCTIONS

Hex Code	Mnemonic	Operands
74	MOV	A, #data
E6	MOV	A, @R0
E7		R1
E*	MOV	A, Rr
E5	MOV	A, data addr
F6	MOV	@R0, A
F7		R1
76	MOV	@R0, #data
77		R1
A6	MOV	@R0, data addr
A7		R1
F*	MOV	Rr, A
7*	MOV	Rr, #data
A*	MOV	Rr, data addr
F5	MOV	data addr, A
75	MOV	data addr, #data
86	MOV	data addr, @R0
87		R1
8*	MOV	data addr, Rr
85	MOV	data addr, data addr
90	MOV	DPTR, #data *
93	MOVC	A, @A + DPTR
83	MOVC	A, @A + PC
E0	MOVX	A, @DPTR
E2	MOVX	A, @R0
E3		R1
F0	MOVX	@DPTR, A
F2	MOVX	@R0, A
F3		R1
C0	PUSH	data addr
D0	POP	data addr
C**	XCH	A, Rr
C5	XCH	A, data addr
C6	XCH	A, R0
C7		R1
D6	XCHD	A, @R0
D7		R1

## BIT MANIPULATION INSTRUCTIONS

Hex Code	Mnemonic	Operands
C3	CLR	C
C2	CLR	bit addr
D3	SETB	C
D2	SETB	bit addr
B3	CPL	C
B2	CPL	bit addr
82	ANL	C, bit addr
B0	ANL	C, lbit addr
72	ORL	C, bit addr
A0	ORL	C, lbit addr
A2	MOV	C, bit addr
92	MOV	bit addr, C

## NO OPERATION

Hex Code	Mnemonic
00	NOP

\* 16-bit data operand.

\*\* See page 7 for instruction's hex code.

# PROGRAM AND MACHINE CONTROL INSTRUCTIONS

Hex Code	Mnemonic	Operands
t1	AJMP	<i>code addr</i>
B6	CJNE	<i>(R0, #data, code addr</i>
B7		<i>R1</i>
B4	CJNE	<i>A, #data, code addr</i>
B5	CJNE	<i>A, data addr, code addr</i>
B*	CJNE	<i>Rr, #data, code addr</i>
D*	DJNZ	<i>Rr, code addr</i>
D5	DJNZ	<i>data addr, code addr</i>
20	JB	<i>bit addr, code addr</i>
10	JBC	<i>bit addr, code addr</i>
40	JC	<i>code addr</i>
73	JMP	<i>A + DPTR</i>
30	JNB	<i>bit addr, code addr</i>
50	JNC	<i>code addr</i>
70	JNZ	<i>code addr</i>
60	JZ	<i>code addr</i>
02	LJMP	<i>code addr</i>
80	SJMP	<i>code addr</i>
t1	ACALL	<i>code addr</i>
12	LCALL	<i>code addr</i>
22	RET	
32	RETI	
**	JMP	<i>code addr</i>
**	CALL	<i>code addr</i>

# CODES FOR INSTRUCTIONS USING REGISTERS

	MOV Rr, A	MOV Rr, #data	MOV A, Rr	MOV data addr, Rr
R0	F8H	78H	E8H	88H
R1	F9H	79H	E9H	89H
R2	FAH	7AH	EAH	8AH
R3	FBH	7BH	EBH	8BH
R4	FBH	7CH	ECH	8CH
R5	FDH	7DH	EDH	8DH
R6	FEH	7EH	EEH	8EH
R7	FFH	7FH	EFH	8FH
	XCH A, Rr	XRL A, Rr	INC Rr	MOV Rr, data addr
R0	C8H	68H	08H	A8H
R1	C9H	69H	09H	A9H
R2	CAH	6AH	0AH	AAH
R3	CBH	6BH	0BH	ABH
R4	CBH	6CH	0CH	ABH
R5	CDH	6DH	0DH	ADH
R6	CEH	6EH	0EH	AEH
R7	CFH	6FH	0FH	AFH
	ADD A, Rr	ADDC A, Rr	ANL A, Rr	CJNE Rr, #data, code addr
R0	28H	38H	58H	B8H
R1	29H	39H	59H	B9H
R2	2AH	3AH	5AH	BAH
R3	2BH	3BH	5BH	BBH
R4	2CH	3CH	5CH	BBH
R5	2DH	3DH	5DH	BDH
R6	2EH	3EH	5EH	BEH
R7	2FH	3FH	5FH	BFH
	ORL A, Rr	SUBB A, Rr	DEC Rr	DJNZ Rr, code addr
R0	48H	98H	18H	D8H
R1	49H	99H	19H	D9H
R2	4AH	9AH	1AH	DAH
R3	4BH	9BH	1BH	DBH
R4	4CH	9CH	1CH	DCH
R5	4DH	9DH	1DH	DDH
R6	4EH	9EH	1EH	DEH
R7	4FH	9FH	1FH	DFH

t First three bits of the opcode are formed by the code address operand

\* See page 7 for instruction's hex code.

\*\* Generic form of instruction.



## PREDEFINED BYTE ADDRESSES

Symbol	Hex Address	Meaning
ACC	E0	ACCUMULATOR
B	F0	MULTIPLICATION REGISTER
DPH	83	DATA POINTER <high byte>
DPL	82	DATA POINTER <low byte>
IE	A8	INTERRUPT ENABLE
IP	B8	INTERRUPT PRIORITY
P0	80	PORT 0
P1	90	PORT 1
P2	A0	PORT 2
P3	B0	PORT 3
PSW	D0	PROGRAM STATUS WORD
SBUF	99	SERIAL PORT BUFFER
SCON	98	SERIAL PORT CONTROL
SP	81	STACK POINTER
TCON	88	TIMER CONTROL
TH0	8C	TIMER 0 <high byte>
TH1	8D	TIMER 1 <high byte>
TL0	8A	TIMER 0 <low byte>
TL1	8B	TIMER 1 <low byte>
TMOD	89	TIMER MODE

## PREDEFINED BIT ADDRESSES

Sym.	Position	Hex	Meaning
CY	PSW.7	D7	CARRY FLAG
AC	PSW.6	D6	AUXILIARY CARRY FLAG
F0	PSW.5	D5	FLAG 0
RS1	PSW.4	D4	REGISTER BANK SELECT BIT 1
RS0	PSW.3	D3	REGISTER BANK SELECT BIT 0
OV	PSW.2	D2	OVERFLOW FLAG
P	PSW.0	D0	PARITY FLAG
TF1	TCON.7	8F	TIMER 1 OVERFLOW FLAG
TR1	TCON.6	8E	TIMER 1 RUN CONTROL BIT
TF0	TCON.5	8D	TIMER 0 OVERFLOW FLAG
TR0	TCON.4	8C	TIMER 0 RUN CONTROL BIT
IE1	TCON.3	8B	INTERRUPT 1 EDGE FLAG
IT1	TCON.2	8A	INTERRUPT 1 TYPE CONTROL BIT
IE0	TCON.1	89	INTERRUPT 0 EDGE FLAG
IT0	TCON.0	88	INTERRUPT 0 TYPE CONTROL BIT
SM0	SCON.7	9F	SERIAL MODE CONTROL BIT 0
SM1	SCON.6	9E	SERIAL MODE CONTROL BIT 1
SM2	SCON.5	9D	SERIAL MODE CONTROL BIT 2
REN	SCON.4	9C	RECEIVE ENABLE
TB8	SCON.3	9B	TRANSMIT BIT 8
RB8	SCON.2	9A	RECEIVE BIT 8
TI	SCON.1	99	TRANSMIT INTERRUPT FLAG
RI	SCON.0	98	RECEIVE INTERRUPT FLAG

## PREDEFINED CODE ADDRESSES

Symbol	Hex Address	Meaning
RESET	00	Power Up (Reset)
EXTI0	03	External Interrupt 0
TIMER0	0B	Timer 0 Interrupt
EXTI1	13	External Interrupt 1
TIMER1	1B	Timer 1 Interrupt
SINT	23	Serial Port Interrupt

EA	IE.7	AF	ENABLE ALL INTERRUPTS
ES	IE.4	AC	ENABLE SERIAL PORT INTERRUPT
ET1	IE.3	AB	ENABLE TIMER 1 INTERRUPT
EX1	IE.2	AA	ENABLE EXTERNAL INTERRUPT 1
ET0	IE.1	A9	ENABLE TIMER 0 INTERRUPT
EX0	IE.0	A8	ENABLE EXTERNAL INTERRUPT 0
PS	IP.4	BC	PRIORITY OF SERIAL PORT INTERRUPT
PT1	IP.3	BB	PRIORITY OF TIMER 1 INTERRUPT
PX1	IP.2	BA	PRIORITY OF EXTERNAL INTERRUPT 1
PT0	IP.1	B9	PRIORITY OF TIMER 0
PX0	IP.0	B8	PRIORITY OF EXTERNAL INTERRUPT 0
RD	P3.7	B7	READ DATA FOR EXTERNAL MEMORY
WR	P3.6	B6	WRITE DATA FOR EXTERNAL MEMORY
T1	P3.5	B5	TIMER/COUNTER 1 EXTERNAL FLAG
T0	P3.4	B4	TIMER/COUNTER 0 EXTERNAL FLAG
INT1	P3.3	B3	INTERRUPT 1 INPUT PIN
INT0	P3.2	B2	INTERRUPT 0 INPUT PIN
TXD	P3.1	B1	SERIAL PORT TRANSMIT PIN
RXD	P3.0	B0	SERIAL PORT RECEIVE PIN

# MACRO PROCESSOR LANGUAGE (MPL) FUNCTIONS

## DEFINING A FUNCTION

%\*DEFINE (macro-name) (replacement-pattern)  
%\*DEFINE (macro-name(parameter-list)) (replacement-pattern)

## MANIPULATING STRINGS

%EVAL(expression)  
%LEN(string)  
%SUBSTR(string,expr1,expr2)  
%IN  
%OUT(string)

## CONTROL FUNCTIONS

%IF (expr) THEN (replacement-value) ELSE  
(replacement-value)FI  
%REPEAT (expr) (replacement-value)  
%WHILE (expr) (replacement-value)  
%SET(name, value)  
%MATCH(name1 name2) (list)  
%MATCH(name1 delimiter name2) (string)

## INTERPRETATION-CONTROLLING FUNCTIONS

%(balanced-text)  
%cnxxx...x  
    n  
%EXIT  
%comment-text'  
or:  
%comment-text linefeed  
%METACHAR(char)

## COMPARING STRINGS LEXICALLY

%EQS  
%NES  
%LTS  
%LES  
%GTS  
%GES } (string1, string2)

# ASSEMBLY TIME EXPRESSION OPERATORS

In order of decreasing precedence

( )  
HIGH, LOW  
\*, /, MOD, SHR, SHL  
+, -  
EQ, LT, GT, LE, GE, NE, =, <, >, <=, >=, <>  
NOT  
AND  
OR, XOR

## ASSEMBLER DIRECTIVES

Directive	Meaning
SEGMENT	Define a relocatable segment
EQU	Assign a numeric value or special assembler symbol
SET	Set symbol value
DATA	Define a data address symbol
IDATA	Define an indirect internal data address symbol
XDATA	Define an off chip data address symbol
BIT	Assign a bit address symbol
CODE	Assign a code address symbol
DS	Reserve space in byte units
DB	Insert a list of byte values
DW	Insert a list of word values
DBIT	Advance bit location counter
PUBLIC	Declare symbols outside current module
EXTRN	List symbols defined in other modules
NAME	Identify current program module
ORG	Set location counter value
END	End of program
RSEG	Select a relocatable segment
CSEG	Select an absolute segment within code address space
DSEG	Select an absolute segment within internal data address space
XSEG	Select an absolute segment within external data address space
ISEG	Select an absolute segment within indirect internal data address space
BSEG	Select an absolute segment within the bit data address space
USING	Select predefined symbolic register banks

# TABLE OF INSTRUCTION OPCODES IN HEXADECIMAL ORDER

Hex Code	Number of Bytes	Mnemonic	Operands
00	1	NOP	
01	2	AJMP	<i>code addr</i>
02	3	LJMP	<i>code addr</i>
03	1	RR	A
04	1	INC	A
05	2	INC	<i>data addr</i>
06	1	INC	@ R0
07	1	INC	@ R1
08	1	INC	R0
09	1	INC	R1
0A	1	INC	R2
0B	1	INC	R3
0C	1	INC	R4
0D	1	INC	R5
0E	1	INC	R6
0F	1	INC	R7
10	3	JBC	<i>bit addr.code addr</i>
11	2	ACALL	<i>code addr</i>
12	3	LCALL	<i>code addr</i>
13	1	RRC	A
14	1	DEC	A
15	2	DEC	<i>data addr</i>
16	1	DEC	@ R0
17	1	DEC	@ R1
18	1	DEC	R0
19	1	DEC	R1
1A	1	DEC	R2
1B	1	DEC	R3
1C	1	DEC	R4
1D	1	DEC	R5
1E	1	DEC	R6
1F	1	DEC	R7
20	3	JB	<i>bit addr.code addr</i>
21	2	AJMP	<i>code addr</i>
22	1	RET	
23	1	RL	A
24	2	ADD	A, # <i>data</i>
25	2	ADD	A, <i>data addr</i>
26	1	ADD	A, @ R0
27	1	ADD	A, @ R1
28	1	ADD	A, R0
29	1	ADD	A, R1
2A	1	ADD	A, R2

# TABLE OF INSTRUCTION OPCODES IN HEXADECIMAL ORDER (Cont'd.)

Hex Code	Number of Bytes	Mnemonic	Operands
2B	1	ADD	A, R3
2C	1	ADD	A, R4
2D	1	ADD	A, R5
2E	1	ADD	A, R6
2F	1	ADD	A, R7
30	3	JNB	<i>bit addr.code addr</i>
31	2	ACALL	<i>code addr</i>
32	1	RETI	
33	1	RLC	A
34	2	ADDC	A, # <i>data</i>
35	2	ADDC	A, <i>data addr</i>
36	1	ADDC	A, @ R0
37	1	ADDC	A, @ R1
38	1	ADDC	A, R0
39	1	ADDC	A, R1
3A	1	ADDC	A, R2
3B	1	ADDC	A, R3
3C	1	ADDC	A, R4
3D	1	ADDC	A, R5
3E	1	ADDC	A, R6
3F	1	ADDC	A, R7
40	2	JC	<i>code addr</i>
41	2	AJMP	<i>code addr</i>
42	2	ORL	<i>data addr.A</i>
43	3	ORL	<i>data addr.#data</i>
44	2	ORL	A, # <i>data</i>
45	2	ORL	A, <i>data addr</i>
46	1	ORL	A, @ R0
47	1	ORL	A, @ R1
48	1	ORL	A, R0
49	1	ORL	A, R1
4A	1	ORL	A, R2
4B	1	ORL	A, R3
4C	1	ORL	A, R4
4D	1	ORL	A, R5
4E	1	ORL	A, R6
4F	1	ORL	A, R7
50	2	JNC	<i>code addr</i>
51	2	ACALL	<i>code addr</i>
52	2	ANL	<i>data addr.A</i>
53	3	ANL	<i>data addr.#data</i>
54	2	ANL	A, # <i>data</i>
55	2	ANL	A, <i>data addr</i>

**TABLE OF INSTRUCTION OPCODES IN  
HEXADECIMAL ORDER (Cont'd.)**

Hex Code	Number of Bytes	Mnemonic	Operands
56	1	ANL	A, <i>@R0</i>
57	1	ANL	A, <i>@R1</i>
58	1	ANL	A, R0
59	1	ANL	A, R1
5A	1	ANL	A, R2
5B	1	ANL	A, R3
5C	1	ANL	A, R4
5D	1	ANL	A, R5
5E	1	ANL	A, R6
5F	1	ANL	A, R7
60	2	JZ	<i>code addr</i>
61	2	AJMP	<i>code addr</i>
62	2	XRL	<i>data addr</i> , A
63	3	XRL	<i>data addr</i> , <i>#data</i>
64	2	XRL	A, <i>#data</i>
65	2	XRL	A, <i>data addr</i>
66	1	XRL	A, <i>@R0</i>
67	1	XRL	A, <i>@R1</i>
68	1	XRL	A, R0
69	1	XRL	A, R1
6A	1	XRL	A, R2
6B	1	XRL	A, R3
6C	1	XRL	A, R4
6D	1	XRL	A, R5
6E	1	XRL	A, R6
6F	1	XRL	A, R7
70	2	JNZ	<i>code addr</i>
71	2	ACALL	<i>code addr</i>
72	2	ORL	C, <i>bit addr</i>
73	1	JMP	<i>@A</i> + DPTR
74	2	MOV	A, <i>#data</i>
75	3	MOV	<i>data addr</i> , <i>#data</i>
76	2	MOV	<i>@R0</i> , <i>#data</i>
77	2	MOV	<i>@R1</i> , <i>#data</i>
78	2	MOV	R0, <i>#data</i>
79	2	MOV	R1, <i>#data</i>
7A	2	MOV	R2, <i>#data</i>
7B	2	MOV	R3, <i>#data</i>
7C	2	MOV	R4, <i>#data</i>
7D	2	MOV	R5, <i>#data</i>
7E	2	MOV	R6, <i>#data</i>
7F	2	MOV	R7, <i>#data</i>
80	2	SJMP	<i>code addr</i>

**TABLE OF INSTRUCTION OPCODES IN  
HEXADECIMAL ORDER (Cont'd.)**

Hex Code	Number of Bytes	Mnemonic	Operands
81	2	AJMP	<i>code addr</i>
82	2	ANL	C, <i>bit addr</i>
83	1	MOVC	A, <i>@A</i> + PC
84	1	DIV	AB
85	3	MOV	<i>data addr</i> , <i>data addr</i>
86	2	MOV	<i>data addr</i> , <i>@R0</i>
87	2	MOV	<i>data addr</i> , <i>@R1</i>
88	2	MOV	<i>data addr</i> , R0
89	2	MOV	<i>data addr</i> , R1
8A	2	MOV	<i>data addr</i> , R2
8B	2	MOV	<i>data addr</i> , R3
8C	2	MOV	<i>data addr</i> , R4
8D	2	MOV	<i>data addr</i> , R5
8E	2	MOV	<i>data addr</i> , R6
8F	2	MOV	<i>data addr</i> , R7
90	3	MOV	DPTR, <i>#data</i>
91	2	ACALL	<i>code addr</i>
92	2	MOV	<i>bit addr</i> , C
93	1	MOVC	A, <i>@A</i> + DPTR
94	2	SUBB	A, <i>#data</i>
95	2	SUBB	A, <i>data addr</i>
96	1	SUBB	A, <i>@R0</i>
97	1	SUBB	A, <i>@R1</i>
98	1	SUBB	A, R0
99	1	SUBB	A, R1
9A	1	SUBB	A, R2
9B	1	SUBB	A, R3
9C	1	SUBB	A, R4
9D	1	SUBB	A, R5
9E	1	SUBB	A, R6
9F	1	SUBB	A, R7
A0	2	ORL	C, <i>bit addr</i>
A1	2	AJMP	<i>code addr</i>
A2	2	MOV	C, <i>bit addr</i>
A3	1	INC	DPTR
A4	1	MUL	AB
A5		reserved	
A6	2	MOV	<i>@R0</i> , <i>data addr</i>
A7	2	MOV	<i>@R1</i> , <i>data addr</i>
A8	2	MOV	R0, <i>data addr</i>
A9	2	MOV	R1, <i>data addr</i>
AA	2	MOV	R2, <i>data addr</i>
AB	2	MOV	R3, <i>data addr</i>

TABLE OF INSTRUCTION OPCODES IN  
HEXADECIMAL ORDER (Cont'd.)

Hex Code	Number of Bytes	Mnemonic	Operands
AC	2	MOV	R4.data addr
AD	2	MOV	R5.data addr
AE	2	MOV	R6.data addr
AF	2	MOV	R7.data addr
B0	2	ANL	C,1 bit addr
B1	2	ACALL	code addr
B2	2	CPL	bit addr
B3	1	CPL	C
B4	3	CJNE	A, #data.code addr
B5	3	CJNE	A.data addr.code addr
B6	3	CJNE	ri R0.#data.code addr
B7	3	CJNE	ri R1.#data.code addr
B8	3	CJNE	R0.#data.code addr
B9	3	CJNE	R1.#data.code addr
BA	3	CJNE	R2.#data.code addr
BB	3	CJNE	R3.#data.code addr
BC	3	CJNE	R4.#data.code addr
BD	3	CJNE	R5.#data.code addr
BE	3	CJNE	R6.#data.code addr
BF	3	CJNE	R7.#data.code addr
C0	2	PUSH	data addr
C1	2	AJMP	code addr
C2	2	CLR	bit addr
C3	1	CLR	C
C4	1	SWAP	A
C5	2	XCH	A.data addr
C6	1	XCH	A,ri R0
C7	1	XCH	A,ri R1
C8	1	XCH	A,R0
C9	1	XCH	A,R1
CA	1	XCH	A,R2
CB	1	XCH	A,R3
CC	1	XCH	A,R4
CD	1	XCH	A,R5
CE	1	XCH	A,R6
CF	1	XCH	A,R7
D0	2	POP	data addr
D1	2	ACALL	code addr
D2	2	SETB	bit addr
D3	1	SETB	C
D4	1	DA	A
D5	3	DJNZ	data addr.code addr
D6	1	XCHD	A,ri R0

TABLE OF INSTRUCTION OPCODES IN  
HEXADECIMAL ORDER (Cont'd.)

Hex Code	Number of Bytes	Mnemonic	Operands
D7	1	XCHD	A,@ R1
D8	2	DJNZ	R0.code addr
D9	2	DJNZ	R1.code addr
DA	2	DJNZ	R2.code addr
DB	2	DJNZ	R3.code addr
DC	2	DJNZ	R4.code addr
DD	2	DJNZ	R5.code addr
DE	2	DJNZ	R6.code addr
DF	2	DJNZ	R7.code addr
E0	1	MOVX	A,@ DPTR
E1	2	AJMP	code addr
E2	1	MOVX	A,ri R0
E3	1	MOVX	A,ri R1
E4	1	CLR	A
E5	2	MOV	A.data addr
E6	1	MOV	A,ri R0
E7	1	MOV	A,ri R1
E8	1	MOV	A,R0
E9	1	MOV	A,R1
EA	1	MOV	A,R2
EB	1	MOV	A,R3
EC	1	MOV	A,R4
ED	1	MOV	A,R5
EE	1	MOV	A,R6
EF	1	MOV	A,R7
F0	1	MOVX	@ DPTR.A
F1	2	ACALL	code addr
F2	1	MOVX	@ R0.A
F3	1	MOVX	@ R1.A
F4	1	CPL	A
F5	2	MOV	data addr.A
F6	1	MOV	@ R0.A
F7	1	MOV	@ R1.A
F8	1	MOV	R0.A
F9	1	MOV	R1.A
FA	1	MOV	R2.A
FB	1	MOV	R3.A
FC	1	MOV	R4.A
FD	1	MOV	R5.A
FE	1	MOV	R6.A
FF	1	MOV	R7.A

# HEX-ASCII Table

NUL	00	-	2B	V	56
SOH	01	-	2C	W	57
STX	02	-	2D	X	58
ETX	03	-	2E	Y	59
EOT	04	-	2F	Z	5A
ENO	05	0	30	[	5B
ACK	06	1	31	\	5C
BEL	07	2	32	]	5D
BS	08	3	33	^	5E
HT	09	4	34	_	5F
LF	0A	5	35	`	60
VT	0B	6	36	a	61
FF	0C	7	37	b	62
CR	0D	8	38	c	63
SC	0E	9	39	d	64
S	0F	A	3A	e	65
DLE	10	B	3B	f	66
DC1-AON	11	C	3C	g	67
DC2-TAPE	12	D	3D	h	68
DC3-OFF	13	E	3E	i	69
DC4-TAPE	14	F	3F	j	6A
NAK	15	G	40	k	6B
SYN	16	H	41	l	6C
ETB	17	I	42	m	6D
CAN	18	J	43	n	6E
EM	19	K	44	o	6F
END	1A	L	45	p	70
ESC	1B	M	46	q	71
DC5-TAPE	1C	N	47	r	72
DC6-TAPE	1D	O	48	s	73
DC7-TAPE	1E	P	49	t	74
DC8-TAPE	1F	Q	4A	u	75
DC9-TAPE	20	R	4B	v	76
DC10-TAPE	21	S	4C	w	77
DC11-TAPE	22	T	4D	x	78
DC12-TAPE	23	U	4E	y	79
DC13-TAPE	24	V	4F	z	7A
DC14-TAPE	25	W	50	[	7B
DC15-TAPE	26	X	51	\	7C
DC16-TAPE	27	Y	52	]	7D
DC17-TAPE	28	Z	53	^	7E
DC18-TAPE	29	[	54	_	7F
DC19-TAPE	2A	\	55	`	80
DC20-TAPE	2B	]	56	a	81
DC21-TAPE	2C	^	57	b	82
DC22-TAPE	2D	_	58	c	83
DC23-TAPE	2E	`	59	d	84
DC24-TAPE	2F	a	5A	e	85
DC25-TAPE	30	b	5B	f	86
DC26-TAPE	31	c	5C	g	87
DC27-TAPE	32	d	5D	h	88
DC28-TAPE	33	e	5E	i	89
DC29-TAPE	34	f	5F	j	8A
DC30-TAPE	35	g	60	k	8B
DC31-TAPE	36	h	61	l	8C
DC32-TAPE	37	i	62	m	8D
DC33-TAPE	38	j	63	n	8E
DC34-TAPE	39	k	64	o	8F
DC35-TAPE	3A	l	65	p	90
DC36-TAPE	3B	m	66	q	91
DC37-TAPE	3C	n	67	r	92
DC38-TAPE	3D	o	68	s	93
DC39-TAPE	3E	p	69	t	94
DC40-TAPE	3F	q	6A	u	95
DC41-TAPE	40	r	6B	v	96
DC42-TAPE	41	s	6C	w	97
DC43-TAPE	42	t	6D	x	98
DC44-TAPE	43	u	6E	y	99
DC45-TAPE	44	v	6F	z	9A
DC46-TAPE	45	w	70	[	9B
DC47-TAPE	46	x	71	\	9C
DC48-TAPE	47	y	72	]	9D
DC49-TAPE	48	z	73	^	9E
DC50-TAPE	49	[	74	_	9F
DC51-TAPE	4A	\	75	`	A0
DC52-TAPE	4B	]	76	a	A1
DC53-TAPE	4C	^	77	b	A2
DC54-TAPE	4D	_	78	c	A3
DC55-TAPE	4E	`	79	d	A4
DC56-TAPE	4F	a	7A	e	A5
DC57-TAPE	50	b	7B	f	A6
DC58-TAPE	51	c	7C	g	A7
DC59-TAPE	52	d	7D	h	A8
DC60-TAPE	53	e	7E	i	A9
DC61-TAPE	54	f	7F	j	AA
DC62-TAPE	55	g	80	k	AB
DC63-TAPE	56	h	81	l	AC
DC64-TAPE	57	i	82	m	AD
DC65-TAPE	58	j	83	n	AE
DC66-TAPE	59	k	84	o	AF
DC67-TAPE	5A	l	85	p	B0
DC68-TAPE	5B	m	86	q	B1
DC69-TAPE	5C	n	87	r	B2
DC70-TAPE	5D	o	88	s	B3
DC71-TAPE	5E	p	89	t	B4
DC72-TAPE	5F	q	8A	u	B5
DC73-TAPE	60	r	8B	v	B6
DC74-TAPE	61	s	8C	w	B7
DC75-TAPE	62	t	8D	x	B8
DC76-TAPE	63	u	8E	y	B9
DC77-TAPE	64	v	8F	z	BA
DC78-TAPE	65	w	90	[	BB
DC79-TAPE	66	x	91	\	BC
DC80-TAPE	67	y	92	]	BD
DC81-TAPE	68	z	93	^	BE
DC82-TAPE	69	[	94	_	BF
DC83-TAPE	6A	\	95	`	C0
DC84-TAPE	6B	]	96	a	C1
DC85-TAPE	6C	^	97	b	C2
DC86-TAPE	6D	_	98	c	C3
DC87-TAPE	6E	`	99	d	C4
DC88-TAPE	6F	a	9A	e	C5
DC89-TAPE	70	b	9B	f	C6
DC90-TAPE	71	c	9C	g	C7
DC91-TAPE	72	d	9D	h	C8
DC92-TAPE	73	e	9E	i	C9
DC93-TAPE	74	f	9F	j	CA
DC94-TAPE	75	g	A0	k	CB
DC95-TAPE	76	h	A1	l	CC
DC96-TAPE	77	i	A2	m	CD
DC97-TAPE	78	j	A3	n	CE
DC98-TAPE	79	k	A4	o	CF
DC99-TAPE	7A	l	A5	p	D0
DC100-TAPE	7B	m	A6	q	D1
DC101-TAPE	7C	n	A7	r	D2
DC102-TAPE	7D	o	A8	s	D3
DC103-TAPE	7E	p	A9	t	D4
DC104-TAPE	7F	q	AA	u	D5
DC105-TAPE	80	r	AB	v	D6
DC106-TAPE	81	s	AC	w	D7
DC107-TAPE	82	t	AD	x	D8
DC108-TAPE	83	u	AE	y	D9
DC109-TAPE	84	v	AF	z	DA
DC110-TAPE	85	w	B0	[	DB
DC111-TAPE	86	x	B1	\	DC
DC112-TAPE	87	y	B2	]	DD
DC113-TAPE	88	z	B3	^	DE
DC114-TAPE	89	[	B4	_	DF
DC115-TAPE	8A	\	B5	`	E0
DC116-TAPE	8B	]	B6	a	E1
DC117-TAPE	8C	^	B7	b	E2
DC118-TAPE	8D	_	B8	c	E3
DC119-TAPE	8E	`	B9	d	E4
DC120-TAPE	8F	a	BA	e	E5
DC121-TAPE	90	b	BB	f	E6
DC122-TAPE	91	c	BC	g	E7
DC123-TAPE	92	d	BD	h	E8
DC124-TAPE	93	e	BE	i	E9
DC125-TAPE	94	f	BF	j	EA
DC126-TAPE	95	g	C0	k	EB
DC127-TAPE	96	h	C1	l	EC
DC128-TAPE	97	i	C2	m	ED
DC129-TAPE	98	j	C3	n	EE
DC130-TAPE	99	k	C4	o	EF
DC131-TAPE	9A	l	C5	p	F0
DC132-TAPE	9B	m	C6	q	F1
DC133-TAPE	9C	n	C7	r	F2
DC134-TAPE	9D	o	C8	s	F3
DC135-TAPE	9E	p	C9	t	F4
DC136-TAPE	9F	q	CA	u	F5
DC137-TAPE	A0	r	CB	v	F6
DC138-TAPE	A1	s	CC	w	F7
DC139-TAPE	A2	t	CD	x	F8
DC140-TAPE	A3	u	CE	y	F9
DC141-TAPE	A4	v	CF	z	FA
DC142-TAPE	A5	w	D0	[	FB
DC143-TAPE	A6	x	D1	\	FC
DC144-TAPE	A7	y	D2	]	FD
DC145-TAPE	A8	z	D3	^	FE
DC146-TAPE	A9	[	D4	_	FF
DC147-TAPE	AA	\	D5	`	100
DC148-TAPE	AB	]	D6	a	101
DC149-TAPE	AC	^	D7	b	102
DC150-TAPE	AD	_	D8	c	103
DC151-TAPE	AE	`	D9	d	104
DC152-TAPE	AF	a	DA	e	105
DC153-TAPE	B0	b	DB	f	106
DC154-TAPE	B1	c	DC	g	107
DC155-TAPE	B2	d	DD	h	108
DC156-TAPE	B3	e	DE	i	109
DC157-TAPE	B4	f	DF	j	110
DC158-TAPE	B5	g	E0	k	111
DC159-TAPE	B6	h	E1	l	112
DC160-TAPE	B7	i	E2	m	113
DC161-TAPE	B8	j	E3	n	114
DC162-TAPE	B9	k	E4	o	115
DC163-TAPE	BA	l	E5	p	116
DC164-TAPE	BB	m	E6	q	117
DC165-TAPE	BC	n	E7	r	118
DC166-TAPE	BD	o	E8	s	119
DC167-TAPE	BE	p	E9	t	120
DC168-TAPE	BF	q	EA	u	121
DC169-TAPE	C0	r	EB	v	122
DC170-TAPE	C1	s	EC	w	123
DC171-TAPE	C2	t	ED	x	124
DC172-TAPE	C3	u	EE	y	125
DC173-TAPE	C4	v	EF	z	126
DC174-TAPE	C5	w	F0	[	127
DC175-TAPE	C6	x	F1	\	128
DC176-TAPE	C7	y	F2	]	129
DC177-TAPE	C8	z	F3	^	130
DC178-TAPE	C9	[	F4	_	131
DC179-TAPE	CA	\	F5	`	132
DC180-TAPE	CB	]	F6	a	133
DC181-TAPE	CC	^	F7	b	134
DC182-TAPE	CD	_	F8	c	135
DC183-TAPE	CE	`	F9	d	136
DC184-TAPE	CF	a	FA	e	137
DC185-TAPE	D0	b	FB	f	138
DC186-TAPE	D1	c	FC	g	139
DC187-TAPE	D2	d	FD	h	140
DC188-TAPE	D3	e	FE	i	141
DC189-TAPE	D4	f	FF	j	142
DC190-TAPE	D5	g	100	k	143
DC191-TAPE	D6	h	101	l	144
DC192-TAPE	D7	i	102	m	145
DC193-TAPE	D8	j	103	n	146
DC194-TAPE	D9	k	104	o	147
DC195-TAPE	DA	l	105	p	148
DC196-TAPE	DB	m	106	q	149
DC197-TAPE	DC	n	107	r	150
DC198-TAPE	DD	o	108	s	151
DC199-TAPE	DE	p	109	t	152
DC200-TAPE	DF	q	110	u	153
DC201-TAPE	E0	r	111	v	154
DC202-TAPE	E1	s	112	w	155
DC203-TAPE	E2	t	113	x	156
DC204-TAPE	E3	u	114	y	157
DC205-TAPE	E4	v	115	z	158
DC206-TAPE	E5	w	116	[	159
DC207-TAPE	E6	x	117	\	160
DC208-TAPE	E7	y	118	]	161
DC209-TAPE	E8	z	119	^	162
DC210-TAPE	E9	[	120	_	163
DC211-TAPE	EA	\	121	`	164
DC212-TAPE	EB	]	122	a	165
DC213-TAPE	EC	^	123	b	166
DC214-TAPE	ED	_	124	c	167
DC215-TAPE	EE	`	125	d	168
DC216-TAPE	EF	a	126	e	169
DC217-TAPE	F0	b	127	f	170
DC218-TAPE	F1	c	128	g	171
DC219-TAPE	F2	d	129	h	172
DC220-TAPE	F3	e	130	i	173
DC221-TAPE	F4	f	131	j	174
DC222-TAPE	F5	g	132	k	175
DC223-TAPE	F6	h	133	l	176
DC224-TAPE	F7	i	134	m	177
DC225-TAPE	F8	j	135	n	178
DC226-TAPE	F9	k	136	o	179
DC227-TAPE	FA	l	137	p	180
DC228-TAPE	FB	m	138	q	181
DC229-TAPE	FC	n	139	r	182
DC230-TAPE	FD	o	140	s	183
DC231-TAPE	FE	p	141	t	184
DC232-TAPE	FF	q	142	u	185
DC233-TAPE	100	r	143	v	186
DC234-TAPE	101	s	144	w	187
DC235-TAPE	102	t	145	x	188
DC236-TAPE	103	u	146	y	189
DC237-TAPE	104	v	147	z	190
DC238-TAPE	105	w	148	[	191
DC239-TAPE	106	x	149	\	192
DC240-TAPE	107	y	150	]	193
DC241-TAPE	108	z	151	^	194
DC242-TAPE	109	[	152	_	195
DC243-TAPE	110</				